

PVC FLOORING INSTALLATION

FIX THE CRACKS IN SUBFLOOR

To make the flooring rolls adapt construction site condition, it should have a pre-installation process.

- Make sure the subfloor is smooth, hard, clean and dry
- Pave an effective damp proof membrane on subfloor
- Open the package, put the flooring in one pile (surface to surface, bottom to bottom, at least 20 layers)

The flooring must be allowed to acclimatize 24 hours before installation and the room temperature need to be between 18-24 degree centigrade.

