

PVC FLOORING INSTALLATION

CORNER INSTALLATION OF FLOORING TILES

1. Put "a" on "b"
2. Cut according to the right side of "a"
3. "b" will be divided into "c" and "d"
4. Put "d" into the interstice
5. Use a similar color wall-base to make everything perfect

