

PVC FLOORING INSTALLATION

SELF-LEVELING INSTALLATION

Self-leveling is used to make the subfloor flat and improve its strength before install vinyl flooring. Inspect the flatness again and make sure the height difference is less than 2mm.

Process

- Mix self-leveling and water according to its product introduction
- Keep stirring by using blender at least 2 mins, and re-stirring after 1 mins
- Pour the self-leveling paste onto subfloor, and use rake make it flat (2-3mm according to subfloor situation)
- Use long tine spiked roller to remove the bubbles in self-leveling paste
- Wait 24 hours drying time

Suggested product

TOSION 666

25kg/bag (6-7sq.m.)

Tools

- Blender
- Rake
- Long tine spiked roller
- Spike Shoes

