

PVC FLOORING INSTALLATION

SEAL THE SUBFLOOR WITH PRIMER

Primer is used to lose the pore and crack on subfloor, reduce the absorptive character, at the same time, it can increase the adhesive ability between subfloor and adhesive.

Absorbent subfloor (Cement, concrete)

Use absorbent primer *TOSION 623*

20kg/bucket

160-180sq.m./bucket

Wait 1-2 hours according to local situation

Non-absorbent subfloor (Marble, ceramic, glass)

Use non-absorbent primer *TOSION 538*

5kg/bucket

120-140sq.m./bucket

Wait it totally dry

Tools

- Roller brush

