

# FAQ

## HOW TO DEAL WITH SUBFLOOR CRAZE

### Small crack

- Seal with suitable primer

### Big crack

- Cut the crack
- Clean the dust
- Fill with double-component polyurethane repair adhesive and stainless-steel bar

### Expansion joint

- Without the agreement from designer, don't install self-leveling in this area

